

FIELD MANUAL  
NO. 23-90  
TECHNICAL ORDER  
NO. 11W2-5-13-21

\*FM 23-90/TO 11W2-5-13-21  
DEPARTMENTS OF THE ARMY  
AND THE AIR FORCE  
WASHINGTON, DC, \_\_\_\_\_

HEADQ

# MORTARS

## CONTENTS

	Page
PREFACE .....	ix
<b>CHAPTER 1. INTRODUCTION</b>	
Section     I. General Doctrine .....	1-1
1-1. Effective Mortar Fire.....	1-1
1-2. Mortar Positions .....	1-2
Section     II. Indirect Fire Team.....	1-2
1-3. Applications .....	1-2
1-4. Team Mission.....	1-3
Section     III. Safety Procedures .....	1-3
1-5. Duties of the Safety Officer and Supervisory Personnel.....	1-3
1-6. Ammunition Care and Handling .....	1-9
1-7. Field Storage of Ammunition.....	1-10
<b>CHAPTER 2. SIGHTING AND FIRE CONTROL EQUIPMENT</b>	
Section     I. Compass, M2 .....	2-1
2-1. Characteristics .....	2-1
2-2. Description .....	2-2
2-3. Use.....	2-2
Section     II. Aiming Circles, M2 and M2A2 .....	2-5
2-4. Characteristics .....	2-5
2-5. Description .....	2-5
2-6. Use.....	2-5
2-7. Accessory Equipment.....	2-8
2-8. Setup and Leveling of Aiming Circle .....	2-9
2-9. Declination Constant.....	2-11
2-10. Orienting of the Instrument on Grid North to Measure Grid Azimuth to Objects .....	2-14
2-11. Measurement of Horizontal Angle Between Two Points.....	2-14

DISTRIBUTION RESTRICTION: Approved for public release, distribution is unlimited.

---

\*This publication supersedes FM 23-90/TO 11W2-5-13-21, 19 September 1990; and TC 23-18, 24 August 1967.

	Page	
2-12.	Orienting of the 0-3200 Line on a Given Grid Azimuth.....	2-15
2-13.	Orienting of the 0-3200 Line on a Given Magnetic Azimuth.....	2-16
2-14.	Verifying the Lay of the Platoon .....	2-16
2-15.	Orienting by Orienting Angle.....	2-17
2-16.	Disassembly of Aiming Circle .....	2-18
2-17.	Care and Maintenance.....	2-18
Section III.	Sightunits .....	2-19
2-18.	Sightunit, M53-Series .....	2-19
2-19.	Operation of M53 Sightunit .....	2-21
2-20.	Care and Maintenance of M53 Sightunit .....	2-22
2-21.	Sightunit, M64-Series .....	2-23
2-22.	Sightunit, M67 .....	2-26
Section IV.	Boresights.....	2-27
2-23.	Boresight, M45-Series.....	2-27
2-24.	Boresight, M115.....	2-28
2-25.	Principles of Operation .....	2-29
2-26.	Installation.....	2-29
2-27.	Sight Calibration .....	2-30
2-28.	Boresight Method of Calibration .....	2-30
2-29.	Calibration for Deflection Using the M2 Aiming Circle .....	2-32
Section V.	Other Equipment.....	2-34
2-30.	Instrument Light, M53E1 .....	2-34
2-31.	Aiming Posts, M14 and M1A2 .....	2-36
2-32.	Aiming Post Lights, M58 and M59.....	2-37
Section VI.	Laying the Section.....	2-38
2-33.	Reciprocal Laying .....	2-39
2-34.	Reciprocal Laying on a Grid Azimuth .....	2-40
2-35.	Reciprocal Laying on a Magnetic Azimuth.....	2-43
2-36.	Reciprocal Laying Using the Orienting Angle .....	2-43
2-37.	Reciprocal Laying Using the Mortar Sights .....	2-43
2-38.	Reciprocal Laying Using the M2 Compass.....	2-45
2-39.	Placing Out Aiming Posts .....	2-45
2-40.	Alternate Method of Placing Out Aiming Posts .....	2-46
2-41.	Correction for Displacement of Sight .....	2-48
Section VII.	Loading and Firing .....	2-49
2-42.	Firing the Mortar .....	2-49
2-43.	Target Engagement .....	2-50
2-44.	Execution of Fire Commands.....	2-50
2-45.	Arm-and-Hand Signals.....	2-52
2-46.	Subsequent Fire Commands.....	2-53
2-47.	Repeating and Correcting of Fire Commands .....	2-54
2-48.	Reporting of Errors in Firing.....	2-54
2-49.	Night Firing.....	2-54

		Page
<b>CHAPTER 3. 60-mm MORTAR, M224</b>		
Section	I. Squad and Section Organization and Duties .....	3-1
	3-1. Organization .....	3-1
	3-2. Duties .....	3-1
Section	II. Components .....	3-1
	3-3. Tabulated Data .....	3-2
	3-4. Cannon Assembly, M225 .....	3-4
	3-5. Baseplate, M7 .....	3-4
	3-6. Baseplate, M8 .....	3-5
	3-7. Bipod Assembly, M170 .....	3-6
Section	III. Operation.....	3-7
	3-8. Premount Checks .....	3-7
	3-9. Mounting of the Mortar.....	3-7
	3-10. Safety Checks Before Firing .....	3-8
	3-11. Small Deflection and Elevation Changes.....	3-9
	3-12. Large Deflection and Elevation Changes .....	3-9
	3-13. Referring of the Sight and Realignment of Aiming Posts.....	3-10
	3-14. Malfunctions .....	3-12
	3-15. Removal of a Misfire .....	3-12
	3-16. Dismounting and Carrying of the Mortar.....	3-16
Section	IV. Ammunition .....	3-17
	3-17. Classification.....	3-17
	3-18. Color Codes.....	3-18
	3-19. Preparation of Ammunition.....	3-19
	3-20. Types of Fuze.....	3-19
	3-21. Standard B Ammunition .....	3-21
	3-22. Care and Handling.....	3-22
<b>CHAPTER 4. 81-mm MORTAR, M252</b>		
Section	I. Squad and Section Organization and Duties .....	4-1
	4-1. Organization .....	4-1
	4-2. Duties .....	4-1
Section	II. Components .....	4-3
	4-3. Tabulated Data .....	4-4
	4-4. Cannon Assembly, M253 .....	4-5
	4-5. Mount, M177 .....	4-5
	4-6. Baseplate, M3A1 .....	4-6
Section	III. Operation.....	4-7
	4-7. Premount Checks .....	4-7
	4-8. Mounting of the Mortar.....	4-8
	4-9. Safety Checks Before Firing .....	4-9
	4-10. Small Deflection and Elevation Changes.....	4-10
	4-11. Large Deflection and Elevation Changes .....	4-11

	Page	
4-12.	Referring of the Sight and Realignment of Aiming Posts Using M64 Sight.....	4-11
4-13.	Malfunctions .....	4-12
4-14.	Removal of a Misfire .....	4-12
4-15.	Dismounting of the Mortar.....	4-13
Section IV.	Ammunition .....	4-14
4-16.	Classification.....	4-14
4-17.	Function.....	4-16
4-18.	High-Explosive Ammunition.....	4-16
4-19.	Red/White Phosphorus Ammunition .....	4-17
4-20.	Illuminating Ammunition.....	4-18
4-21.	Types of Fuze.....	4-18
4-22.	Characteristics of Proximity Fuze.....	4-20
4-23.	Fuze Wrench and Fuze Setter .....	4-21
4-24.	Preparation of Ammunition.....	4-21
4-25.	Care and Handling.....	4-22

## **CHAPTER 5. 81-mm MORTAR, M29A1**

Section I.	Squad and Section Organization and Duties .....	5-1
5-1.	Organization .....	5-1
5-2.	Duties .....	5-1
Section II.	Components .....	5-2
5-3.	Tabulated Data .....	5-3
5-4.	Cannon Assembly, M29A1 .....	5-4
5-5.	Bipod Assembly, M23A1.....	5-4
5-6.	Baseplate, M3.....	5-5
Section III.	Operation.....	5-6
5-7.	Premount Checks .....	5-6
5-8.	Mounting of the Mortar.....	5-7
5-9.	Safety Checks Before Firing .....	5-19
5-10.	Small Deflection and Elevation Changes.....	5-10
5-11.	Large Deflection and Elevation Changes .....	5-10
5-12.	Referring of the Sight and Realignment of Aiming Posts Using M53 Sight.....	5-12
5-13.	Malfunctions .....	5-12
5-14.	Removal of a Misfire .....	5-12
5-15.	Dismounting of the Mortar.....	5-13
Section IV.	Ammunition .....	5-14
5-16.	Function.....	5-14
5-17.	High-Explosive Ammunition.....	5-15
5-18.	White Phosphorus Ammunition.....	5-15
5-19.	Illuminating Ammunition.....	5-16
5-20.	Types of Fuze .....	5-16
5-21.	Characteristics of Proximity Fuze .....	5-16

		Page
	5-22. Fuze Wrench and Fuze Setter .....	5-16
	5-23. Preparation of Ammunition.....	5-16
	5-24. Care and Handling.....	5-16
 <b>CHAPTER 6. 4.2-INCH MORTAR, M30</b>		
Section	I. Squad and Section Organization and Duties .....	6-1
	6-1. Organization .....	6-1
	6-2. Duties .....	6-1
	6-3. Section Drill and Section Leader Duties .....	6-2
Section	II. Components .....	6-3
	6-4. Tabulated Data .....	6-4
	6-5. Mortar Cannon, M30.....	6-4
	6-6. Mortar Mount, M24A1.....	6-5
Section	III. Operation of Ground-Mounted Mortar .....	6-9
	6-7. Mounting of the Mortar.....	6-9
	6-8. Safety Checks Before Firing .....	6-14
	6-9. Small Deflection Change .....	6-15
	6-10. Large Deflection and Elevation Changes .....	6-15
	6-11. Loading and Firing of M329A2 Round.....	6-16
	6-12. Malfunctions .....	6-16
	6-13. Removal of a Misfire .....	6-17
	6-14. Dismounting of the Mortar.....	6-22
Section	IV. Mortar Carriers, M106, M106A1, and M106A2.....	6-22
	6-15. Description .....	6-22
	6-16. Tabulated Data .....	6-24
Section	V. Operation of Carrier-Mounted Mortar .....	6-25
	6-17. Mortar and Vehicular Mount .....	6-25
	6-18. Maintenance .....	6-27
	6-19. Placement of Mortar Into Firing Position on Carrier .....	6-27
	6-20. Laying for Deflection and Elevation .....	6-29
	6-21. Removal of a Misfire (Carrier-Mounted).....	6-31
	6-22. Mounting of Mortar on Carrier From Ground-Mounted Position.....	6-33
	6-23. Dismounting of Mortar From Carrier.....	6-34
	6-24. Preparation for a March Order From Ground-Mounted Position.....	6-34
	6-25. Safety Checks .....	6-36
	6-26. Measurement of Minimum and Maximum Elevations .....	6-37
	6-27. Squad Formations.....	6-37
	6-28. Dismounted Mortar Squad .....	6-38
	6-29. Reciprocally Laying the Mortar Carrier Section .....	6-39
Section	VI. Ammunition .....	6-40
	6-30. Classification.....	6-40
	6-31. Types of Fuze.....	6-43

	Page
6-32. Preparation of Ammunition.....	6-44
6-33. Care and Handling.....	6-49
<b>CHAPTER 7. 120-mm MORTAR, M120</b>	
Section I. Squad and Section Organization and Duties .....	7-1
7-1. Organization.....	7-1
7-2. Duties .....	7-1
Section II. Components .....	7-2
7-3. Tabulated Data for the 120-mm Mortar, M120.....	7-4
7-4. Barrel Assembly, M298 .....	7-4
7-5. Bipod Assembly, M191 (Carrier-/Ground-Mounted) .....	7-5
7-6. Bipod Assembly, M190 (Ground-Mounted) .....	7-6
7-7. Baseplate, M9.....	7-7
Section III. Operations .....	7-8
7-8. Placing a Ground-Mounted 120-mm Mortar Into Action .....	7-8
7-9. Performing Safety Checks on a Ground-Mounted 120-mm Mortar .....	7-10
7-10. Performing Small Deflection and Elevation Changes on a Ground-Mounted 120-mm Mortar .....	7-10
7-11. Performing Large Deflection and Elevation Changes on a Ground-Mounted 120-mm Mortar .....	7-11
7-12. Malfunctions on a Ground-Mounted 120-mm Mortar .....	7-12
7-13. Performing Misfire Procedures on a Ground-Mounted 120-mm Mortar During Combat .....	7-12
7-14. Loading and Firing the Ground-Mounted 120-mm Mortar.....	7-15
7-15. Taking the 120-mm Mortar Out of Action.....	7-16
Section IV. Mortar Carrier, M1064A3 .....	7-17
7-16. Description .....	7-17
7-17. Tabulated Data for the M1064A3 Carrier .....	7-19
Section V. Operation of a Carrier-Mounted 120-mm Mortar .....	7-20
7-18. Mortar and Vehicular Mount .....	7-20
7-19. Maintenance .....	7-21
7-20. Placing Carrier-Mounted 120-mm Mortar Into Action.....	7-21
7-21. Lay for Deflection and Elevation on a Carrier-Mounted 120-mm Mortar .....	7-22
7-22. Performing Misfire Procedures on a Carrier-Mounted 120-mm Mortar During Combat .....	7-23
7-23. Mounting of the Mortar From a Carrier to a Ground-Mounted Position.....	7-26
7-24. Taking the Mortar Out of Action (Ground-Mounted to M1064A3 Carrier-Mounted).....	7-27
7-25. Performing Safety Checks on a Carrier-Mounted 120-mm Mortar .....	7-28

		Page
Section VI.	7-26. Reciprocally Laying the Mortar Carrier Section .....	7-29
	Ammunition .....	7-30
	7-27. Classification.....	7-30
	7-28. Authorized Cartridges .....	7-30
	7-29. Preparation for Firing .....	7-34
	7-30. Loading and Firing .....	7-35
	7-31. Unfired Cartridges.....	7-35
	7-32. Care and Handling of Cartridges.....	7-36
	7-33. Fuzes .....	7-36
	7-34. Setting Fuzes .....	7-37
7-35. Resetting Fuzes .....	7-39	
 <b>CHAPTER 8. FIRE WITHOUT A FIRE DIRECTION CENTER</b>		
Section I.	Fire Procedures.....	8-1
	8-1. Advantages and Disadvantages .....	8-1
	8-2. Firing Data .....	8-1
	8-3. Observer Corrections .....	8-1
	8-4. Initial Fire Commands.....	8-3
	8-5. Fire Commands .....	8-3
	8-6. Fire Control .....	8-5
	8-7. Movement to Alternate and Supplementary Positions .....	8-5
	8-8. Squad Conduct of Fire .....	8-5
	8-9. Reference Line .....	8-5
	8-10. Fire Adjustment.....	8-5
	8-11. Squad Use of Illumination and Smoke.....	8-6
	8-12. Attack of Wide Targets .....	8-6
8-13. Attack of Deep Targets .....	8-8	
Section II.	Direct-Lay Method .....	8-9
	8-14. Step 1: Initial Firing Data.....	8-9
	8-15. Step 2: Referring the Sight.....	8-10
	8-16. Step 3: Bracketing the Target.....	8-10
	8-17. Step 4: Fire for Effect.....	8-10
Section III.	Direct-Alignment Method .....	8-11
	8-18. Mortar Dismounted .....	8-11
	8-19. Mortar Mounted .....	8-11
	8-20. Natural Object Method .....	8-11
Section IV.	Adjustment of Range.....	8-11
	8-21. Range Spottings .....	8-11
	8-22. Miscellaneous Spottings.....	8-12
	8-23. Bracketing Method.....	8-12
	8-24. Creeping Method of Adjustment.....	8-13
	8-25. Normal Fire Commands .....	8-14
	8-26. Modified Fire Commands .....	8-14
	8-27. Fire Control .....	8-14

	Page
8-28. Establishment of a Reference Line and Shifting From That Line.....	8-15
8-29. Ladder Method of Adjustment .....	8-17
<b>CHAPTER 9. GUNNER'S EXAMINATION</b>	
Section I. Preparatory Instruction .....	9-1
9-1. Methods of Instruction .....	9-1
9-2. Prior Training .....	9-1
9-3. Preparatory Exercises .....	9-1
9-4. Examining Board .....	9-1
9-5. Location and Date .....	9-2
9-6. Eligible Personnel .....	9-2
9-7. Qualification Scores .....	9-3
9-8. General Rules .....	9-3
Section II. Gunner's Examination With Ground-Mounted Mortar .....	9-4
9-9. Subjects and Credits.....	9-4
9-10. Equipment .....	9-4
9-11. Organization.....	9-4
9-12. Procedure.....	9-4
9-13. Mounting of the Mortar.....	9-5
9-14. Small Deflection Change .....	9-12
9-15. Referring of the Sight and Realignment of Aiming Posts.....	9-13
9-16. Large Deflection and Elevation Changes .....	9-15
9-17. Reciprocal Laying .....	9-16
Section III. Gunner's Examination With the Track-Mounted Mortar .....	9-18
9-18. Subjects and Credits.....	9-18
9-19. Equipment .....	9-18
9-20. Organization.....	9-19
9-21. Procedure.....	9-19
9-22. Placement of Mortar Into a Firing Position From Traveling Position .....	9-19
9-23. Small Deflection Change .....	9-21
9-24. Referring of the Sight and Realignment of Aiming Posts.....	9-22
9-25. Large Deflection and Elevation Changes .....	9-24
9-26. Reciprocal Laying .....	9-26
9-27. Support Squad .....	9-27
<b>APPENDIX A. TRAINING DEVICES.....</b>	<b>A-1</b>
<b>APPENDIX B. MORTAR TRAINING STRATEGY .....</b>	<b>B-1</b>
<b>GLOSSARY .....</b>	<b>Glossary-1</b>
<b>REFERENCES .....</b>	<b>References-1</b>
<b>INDEX.....</b>	<b>Index-1</b>